

## **CWM Sealer**

### **Installation Instructions**

Application Fields: Apply to surfaces to prevent negative water coming in contact with the underside of CWM membrane.

Advantages: Easy bonding to porous surfaces

Surface Preparation: After completing surface preparation for Clear Waterproofing Membrane (view installation guide) allow the surface to dry out then apply CWM Sealer

Application Procedure: Using a paint brush paint or roller apply CWM Sealer over area where negative water is expected. (If you have stone apply to entire surface). Apply first coat and after 1-2 mins remove excess. If no excess present reapply removing any excess that does not soak in. Two coats may be required if surface is very porous.

DO NOT allow excess to sit stagnate on tile as it may create a mark.

Allow to cure for 24hrs prior to covering with Clear Waterproofing Membrane or Joint Adhesive

Product Limitations: Sealer only able to work where installed. If movement occurs and the cracks appear in the grout or sub straight, then product may no longer be effective.

Storage: Keep dry and away from direct sunlight, store in temperatures between 4-38 degrees. Lifespan: 12 months if unopened.

Safety & Health: Wear gloves and eye protection in the event of splashes. If contact occurs on eyes wash with water do not rub. With contact on skin wash the affected areas with clean water and soap. If irritation persists, seek medical attention. Keep out of reach of children and always use in well ventilated areas.

If you have any questions regarding application, please contact the office on 02 8012 7216 or [info@remedialmemrbanes.com.au](mailto:info@remedialmemrbanes.com.au)

